

# Installation Instructions



Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

## SPORTLINE Kit – #4.1035

FORD, Mustang, V8 (Incl. Cobra, Exc. Convertible) 1979-1993

FORD, Mustang, (SN95), 4.6 & 5.0/ V8 (Incl. Cobra w/o IRS, Exc. Convertible) 1994>

MERCURY, Capri, V8 1979-1986

Kit Contents	Description	Part Number	Qty
	Front Spring	4.1035F1	2
	Rear Spring	4.1035R	2
	Pinion Snubber	3510.6003	1
	Information Kit	EPAK	1
	Instructions	4.1035INST	1

### NOTES: **Read All Instructions Before Beginning Installation**

- Installation of a **SPORTLINE** Spring set should only be performed by a qualified mechanic experienced in the installation and removal of suspension springs.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.**
- **SPORTLINE** Springs are marked with the letter F and R (located at the end of the part number) designating front and rear springs.
- **SPORTLINE** Springs should be installed with the **Eibach** Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **SPORTLINE** Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
  - Wheel alignment such as camber, caster & toe
  - Tire and/or wheel fender clearance
  - Brake line clearance and attachments
  - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

### ALIGNMENT:

After installation, it will be necessary to perform a full vehicle alignment using factory specifications.

### Bump Stop Trimming Instructions

Typical Bump-Stop

(Bump-Stop from your vehicle may have different shape)

